

Important

1. When you receive your product check the contents for any freight damage or defects.
2. If this is a custom order, the size will be on the outside of the box. Check that it is correct.
3. Advise Newline on 0508 639 5463 if any damage has occurred or if you have any questions about the size within 8 hours of receiving the goods so this can be rectified.
4. Do not install faulty products, as this will void your warranty.

PLEASE READ CAREFULLY

Warranty

1. This covers faulty product. Check **newline.nz** for full details of warranty.
2. Any breakage on site will not be covered.
3. The installation must conform to these instructions for the warranty to apply.
4. Compliance with NZ Building code clause G4 on ventilation is required in a bathroom.
5. Aftercare details in these instructions must be adhered to (page 4).

Health And Safety

- Provide support under wall hung units to simplify installation process.
- Determine positioning of wiring and piping within cavity walls. Mark their position to ensure you are protected and services are not damaged.


Installation Type

Wall Hung Installation: This Page

Materials required

- Masking tape
- Bathroom Silicone (wide adhesion features including plastics)
- Cleaning materials

Tools & Fastenings Required



Complete tiling prior to vanity installation. Warranty claims don't cover renewal of wall finishings.

IMPORTANT NOTICE! (To Both Installer and House Owner/Occupier)

All personnel have the responsibility to protect this basin from damage including impacts or staining as outlined in Aftercare page 3.

Basin Installer

1. Basin position must be established so location of plumbing and framing to mount the basin is in place. (Height top edge of basin: From 800 to 900mm off floor. (Owner/Builder's Choice)
2. Hold Basin in position and mark through fastening holes at back of basin. On the marks use a drill bit no bigger than the core of the screw.
3. Screw in fastenings leaving only thread out past basin hole sufficient for nuts and washers. Install spacer and flat washers and tighten up to complete.
4. Seal join basin-to-wall with silicone.

Plumber

1. Must be a registered plumber with all work to Building Code Compliance.
2. Hot water supply must not exceed 55 degrees.
3. Ensure the water pressure is balanced to the basin size to minimize water splash.

House Owner/Occupier

- Refer to next page for Aftercare information

VANITY CABINET & TOP IS WATERPROOF BUT SEAL JOINTS TO PROTECT STORED ITEMS WITHIN.

To comply with warranty requirements, please ensure the following aftercare procedures are regularly performed. Failure to comply to Warranty Aftercare Instructions will void warranty.

VITREOUS CHINA BASINS AND VANITY TOPS

- Use warm soapy water or mild detergent and a soft or microfiber cloth. Rinse with clean water. and dry off with absorbent cloth.

VANITY CABINETS

- Ensure the water pressure is regulated and balanced to the size of the basin to control water splash.
- The water temperature must be at a maximum of 55 degrees Celsius.
- The waste connections have been correctly installed by a licenced plumber.
- The bathroom must have a suitable ventilation system to remove moisture vapour.
- All cleaning of surfaces: Use a damp microfiber cloth with warm soapy water followed up by drying off with an absorbent cloth.
- Do not use abrasive or aggressive cleaners.

GENERAL

A list of chemicals to avoid contact with the surfaces of your product: hair dyes or lacquers, mineral turps, white spirits, insecticides, nail polish or cleaner, bleaches, shoe polish, mercurochrome, iodine, solvents, alcohol, citrus based chemicals, bath oils, bath salts, kerosene. This is by no means comprehensive but indicative of chemical harm that must be avoided.